



## SW- UPD CHRYSLER® GROUP CAN BUS – L1 (SDD/SBB)

Code: **D727014ZB**

### NEW ITEMS INTRODUCED WITH THE UPDATE:

This SW makes it possible to:

- Addition of new keys (never programmed on the vehicle);
- Addition of old keys (programmed and erased on the vehicle);
- Erasure of all keys;
- Addition of remote controls;
- Reading of immobilizer ID code;
- Reading of errors;
- Deletion of errors.

**NOTE:** to use this SDD/SBB software with the models [CAN], the Switch Adapter CAN BUS (Code D726833ZB) is essential.

**NOTE:** Silca S.p.A. does not provide any type of key.

To enable the new MAKE use the special FORM to apply for a CHRYSLER\* L1 enabling PSW.

When in possession of the PSW, select:

**SETTINGS => ENABLING => IMMOBILIZER => CHRYSLER\* => LEVEL 1;**

Insert the PASSWORD and press **ENTER**.

### PROGRAM INSTALLATION

See instructions booklet provided with CD