



## SW- SPECIAL FUNCTION FNT-04 (SDD/SBB)

Code: **D731008ZB**

### NEW ITEMS INTRODUCED WITH THE UPDATE:

This SW makes it possible to:

- Addition of new keys (never programmed on the vehicle) without the use of the PIN CODE;
- Addition of old keys (programmed and erased on the vehicle) without the use of the PIN CODE;
- Erasure of all keys without the use of the PIN CODE;
- Addition of remote controls without the use of the PIN CODE;
- Reading of immobilizer ID code;
- Reading of errors;
- Deletion of errors.

For the following vehicles:

MODELL	FROM	TO	KEY REFERENCE
<b>CHRYSLER</b>			
300 [CAN]	2004		ORIGINAL
<b>DODGE</b>			
DAKOTA [CAN]	2004	2005	ORIGINAL
DURANGO [CAN]	2004		ORIGINAL
MAGNUM [CAN]	2004		ORIGINAL
<b>JEEP</b>			
G.CHEROKEE [CAN]	2005		ORIGINAL

Through the enabling of the special function FNT-04 (Bypass PIN CODE CHRYSLER) SDD/SBB will be able to Program/Erase keys and remote controls without the use of the PIN CODE and of the SECURITY CODE:

**NOTE: to use this SDD/SBB software with the models [CAN] listed, the Switch Adapter CAN BUS (Code D726833ZB) is essential.**

**NOTE: Silca S.p.A. does not provide any type of key.**

To enable the new MAKE use the special FORM to apply for a CHRYSLER-L1 enabling PSW.

When in possession of the PSW, select:

**SETTINGS => ENABLING => IMMOBILIZER => FNT-04 => LEVEL 0;**

Insert the PASSWORD and press **ENTER**.

### PROGRAM INSTALLATION

See instructions booklet provided with CD