



SW- OPEL[®] RKE-L0 / CB.-L1 (SDD/SBB) Code: D726844ZB

GB NEW ITEMS IN THE UPDATE:

- 1) This SW upgrade makes it possible to:
 - Add/Delete Remote Controls.

NOTE: to use SDD/SBB with the models (CAN) you NEED the CAN BUS Switch Adapter Code D726833ZB.

NOTE: Silca S.p.A. does not provide any type of remote control for any of the models.

To enable the new MAKE, use the special FORM to apply for the PASSWORD to access OPEL[®] REMOTE CONTROLS.

When you have the PSW select:

SETTINGS=>ENABLING=>REMOTE CONTROLS=>OPEL[®]; enter the PASSWORD and press ENTER.

All makes OPEL[®] IMMOBILIZER level 1 and OPEL[®] REMOTE CONTROLS level 0 will be automatically enabled.

PROGRAM INSTALLATION

See instructions booklet with CD.