



SW- PRG OPEL[®] - L0 (SDD/SBB)

Code: **D725567ZB**

NEW ITEMS INTRODUCED WITH THE UPDATE:

This SW makes it possible to:

- Programme/erase keys;
- Check for anomalies stored in the immobilizer memory;
- Delete anomalies stored in the immobilizer memory;
- Read IMMO ID;
- Read the mechanical code of the key 'KEY NUMBER' (figure available only for some car models before the year 2001);

To enable the new MAKE use the special FORM to apply for a OPEL enabling PSW.

When in possession of the PSW, select:

SETTINGS => ENABLING => IMMOBILIZER => OPEL => LEVEL 0;

insert the PASSWORD and press **ENTER**.

PROGRAM INSTALLATION

See instructions booklet provided with CD