



SW- PRG SUZUKI® - L0 (SDD/SBB)
Code: D727375ZB

NEW ITEMS INTRODUCED WITH THE UPDATE:

1) This SW makes it possible to:

- Programme/erase keys;
- Check for anomalies stored in the immobilizer memory;
- Delete anomalies stored in the immobilizer memory;
- Read stored keys number;
- Read IMMO ID.

To enable the new MAKE use the special FORM to apply for SUZUKI® L0 enabling PSW.

When in possession of the PSW, select:

SETTINGS => ENABLING => IMMOBILIZER => SUZUKI® => LEVEL 0;

insert the PASSWORD and press **ENTER**.

PROGRAM INSTALLATION
See instructions booklet provided with CD